

# INSTALLATION GUIDE



**Straight Runs:** Work left to right as viewed from the ground. Lay Leaf4go Micromesh completely flat over existing gutters with the front edge of the panel lined up with the top front edge of the gutter and the back edge lying on the drip edge.



The tab on the left end of each panel installs under the adjoining panel. Use screw holes along the front lip of Leaf4go Micromesh to zip screw the panel - 3 or 4 screws (1, 2 & 3) to the front lip of the gutter and 2 screws for the back (4 & 5). **DIAGRAM 2:** Shows recommended cuts for connecting inside corner pieces together.



## FOR INSIDE CORNERS:

Measure 4.75" in on the front drip edge and mark it. From the double pressed edge to the mark, draw a straight line with a pencil. Cut out this rectangular shape just below the double pressed edge. Do not cut the double pressed edge. (Diagram 2) For the 2nd piece, cut an angled square piece from the corner of the front drip edge to enable overlapping. Connect pieces to form inside corner. Zip screw to gutter.



## FOR OUTSIDE CORNERS:

Using a set square to measure, cut a 45 degree angle using a hand grinder tool on the first piece. Repeat this step for the second piece. Line up the angles to form the outside corner and zip screw to gutter to secure in place.

