

## The Couture Collection!<sup>TM</sup> *Couture Crust*

Couture Crust contains a natural mineral from the earth that appears as brown speckles; these add texture and will create lines when dragged with a trowel. When Crust is worked with a trowel these speckles will crush and make the texture more creamy. Couture Crust requires no primer. Apply to a clean or painted surface with a brush, trowel or roller. It can be stippled with a brush, allowed to set up for an hour then knocked down with a trowel. Crust is beautiful pulled through a stencil. Layer to create a crusty effect. May be thinned with 10% water if desired. The longer it is worked the smoother the consistency. May be tinted\* with Paint Couture!<sup>TM</sup> and glazed. VOC content: <300g/l. \*If tinted use 10% paint and 90% Crust; for a 16 oz. container of Crust add 3 Tablespoons of paint.

---

## The Couture Collection!<sup>TM</sup> *Couture Size*

**Step 1 of 2:** A cracking size used to increase the size of the crackle in Couture Crackle. A must do when painting over flat absorbent surfaces such as Paint Couture! and chalk like paints. Apply to a clean and dry painted surface using a brush or low nap roller. Couture Size dries clear in about an hour and is ready for Couture Crackle. A second coat of Size may applied after the first coat of size has dried (about an hour), all over or randomly to further increase the size of the crackle. When dry the Size will be clear and sticky. Apply one coat of Couture Crackle when the size is dry. See Couture Crackle Below. VOC content: <100g/l

## The Couture Collection!<sup>TM</sup> *Couture Crackle*

**Step 2 of 2:** Couture Crackle is a crackle glaze, it produces a transparent glossy crackle. Using a brush or a Polar Bear Roller apply ONE COAT over 1 - 2 coats of Couture Size that has become clear and tacky (the Size dries in about 1 hour), with a brush or a Polar Bear roller. Apply only 1 coat of Crackle and do not overwork! Do not rush or force dry the crackle with a fan or hair dryer (if done the crackle look very undesirable). Wait until dry (8-12 hours) before applying Glaze Couture!<sup>TM</sup> A light coat of Paint Couture! may be applied over the crackle to add a matte finish, then glaze!  
VOC content: <150g/l