

How to Apply Brilliant White

Brilliant White is a acrylic metallic paint for furniture and cabinets.

Preparation: The surface to be painted must be clean and free of dirt, oil, grease or other contaminates. Use TSP prior to painting on an existing piece of furniture or cabinetry. **Shake or stir well before use.**

In Stencils: Use a Mylar stencil and spray the back of your stencil with Stencil Ease or Martha Stewart's Repositionable Stencil Adhesive and allow to dry at least 5 minutes. Vinyl adhesive stencils are an option as well, they are made to stick to the surface, no need to spray. Place the stencil on the furniture and secure with Blue Tape. Apply the Brilliant White with a foam roller or a stencil brush. Note: When using the foam roller have a piece of cardboard handy and off load your stencil by rolling it a few times on the cardboard, this removes excess paint so it should not bleed under your stencil. Start rolling with light pressure at first this also helps prevent bleeding under the stencil. Clean up is with soap and water.

Full coverage: Brush on with a good quality brush and do not overwork. Brilliant White will dry to a very sparkly, durable finish. On a table top or item that used heavily a top coat of Finish Couture! is recommended. Wait 24 hours before applying Finish Couture!

Sheer Effect: This product may be may be thinned with 10% water for a more transparent look. Brush on top of Paint Couture! for a sheer sparkle!

Over Glaze Effect: Glaze Couture can be brushed on top of Brilliant White after 12 hours.

This product is considered low VOC and contains less than 100 g/l of VOC's.

Brilliant White is not recommended for use directly on metal.