



ES335-V

COLOR CODE

- | | |
|---|---|
| ■ POSITIVE | ■ PRE-SOLDERED |
| ■ NEGATIVE/GROUND | ■ NEW SOLDER POINT |

INSTALLATION INSTRUCTIONS

- Loosen and remove back control plate cover from your guitar.
- Carefully cut original pickup & ground wires as close to the original solder points as possible. **Retain as much original wire as possible.**
- Remove old harness and place new harness.
- Following the diagram, reattach pickups, ground wires and output jack.
- Test for functionality and replace the back cover.

NEED HELP INSTALLING YOUR NEW GEAR?

ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.

855-655-9203