



JB-CON-CH-BK

COLOR CODE

- | | |
|-------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------|
|  POSITIVE |  PRE-SOLDERED |
|  NEGATIVE/GROUND |  NEW SOLDER POINT |

INSTALLATION INSTRUCTIONS

- Loosen control plate from guitar and flip plate over.
- Carefully cut original pickup & ground wires as close to the original solder points as possible. **Retain as much original wire as possible.**
- Place new control plate.
- Following the diagram, reattach pickups, ground wires and output jack.
- Test for functionality and mount new control plate.

NEED HELP INSTALLING YOUR NEW GEAR?

ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.

855-655-9203