

*Please note: your pickups may use wire that is not black or red. This is a graphical representation of how your pickups may look.

COLOR CODE POSITIVE PICKUP NEGATIVE PICKUP NEGATIVE/GROUND PRE-SOLDERED NEW SOLDER POINT

INSTALLATION INSTRUCTIONS

Loosen pickguard from guitar and flip pickguard over.

Carefully cut original pickup & ground wires as close to the original solder points as possible. **Retain as much original wire as possible.**

Dismount all original components and mount new harness into pickguard.

Following the diagram, reattach pickups, ground wires and output jack.

Test for functionality and remount pickguard

ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.

855-655-9203