



S5W-HSS-1T

COLOR CODE

 POSITIVE	 PRE-SOLDERED
 NEGATIVE/GROUND	 NEW SOLDER POINT

INSTALLATION INSTRUCTIONS

- Loosen pickguard from guitar and flip pickguard over.
- Carefully cut original pickup & ground wires as close to the original solder points as possible. Retain as much original wire as possible.
- Dismount all original components and mount new harness into pickguard.
- Following the diagram, reattach pickups, ground wires and output jack.
- Test for functionality and remount pickguard

NEED HELP INSTALLING YOUR NEW GEAR?

ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.

855-655-9203