



## **Terminal Block**

- 1. Body Cavity Ground -
- 2. Tremolo Ground —
- 3. Output Positive +
- 4. Output Negative —
- 5. Bridge Positive +
- 6. Bridge Negative -
- 7. Middle Positive +
- 8. Middle Negative -
- 9. Neck Positive +
- 10. Neck Negative —

## QUICKCONNECT INSTRUCTIONS

- 1. Carefully cut original pickup & ground wires as close to the original solder points as possible. Retain as much original wire as possible.
- 2. From the cut end of your wire, measure and strip back 1/4" (6mm) of insulation.
- 3. Take the loose strands of wire between your fingers and twist, creating a firm tip.
- 4. Use a small screwdriver to press and hold the connector button above the wire slot.
- 5. Insert the wire into the correct slot. For help identifying which wires are which, refer to the documentation that came with your guitar / pickups.
- Release the button and gently pull the wire to ensure it holds firmly in the slot. Repeat steps 2-5 for each wire.
- 7. Shred.