



S7W-2T



INSTALLATION INSTRUCTIONS

- Loosen pickguard from guitar and flip pickguard over.
- Carefully cut original pickup & ground wires as close to the original solder points as possible. Retain as much original wire as possible.
- Dismount all original components and mount new harness into pickguard.
- Following the diagram, reattach pickups, ground wires and output jack.
- Test for functionality and remount pickguard

ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.

855-655-9203