



S7W

COLOR CODE

■ POSITIVE	■ PRE-SOLDERED
■ NEGATIVE/GROUND	■ NEW SOLDER POINT

INSTALLATION INSTRUCTIONS

- Loosen pickguard from guitar and flip pickguard over.
- Carefully cut original pickup & ground wires as close to the original solder points as possible. **Retain as much original wire as possible.**
- Dismount all original components and mount new harness into pickguard.
- Following the diagram, reattach pickups, ground wires and output jack.
- Test for functionality and remount pickguard

NEED HELP INSTALLING YOUR NEW GEAR?

ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.

855-655-9203