



# S9W-H0oP

## COLOR CODE

■ POSITIVE  
■ NEGATIVE/GROUND

■ PRE-SOLDERED  
■ NEW SOLDER POINT

# INSTALLATION INSTRUCTIONS

---

- Loosen pickguard from guitar and flip pickguard over.
- Carefully cut original pickup & ground wires as close to the original solder points as possible. **Retain as much original wire as possible.**
- Dismount all original components and mount new harness into pickguard.
- Following the diagram, reattach pickups, ground wires and output jack.
- Test for functionality and remount pickguard

**NEED HELP INSTALLING YOUR NEW GEAR?**

ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.

**855-655-9203**