



# SG-V

## COLOR CODE

- |   |  |
|---|--|
|  POSITIVE        |  PRE-SOLDERED     |
|  NEGATIVE/GROUND |  NEW SOLDER POINT |

# INSTALLATION INSTRUCTIONS

---

Loosen pickguard from guitar and flip pickguard over.

Carefully cut original pickup & ground wires as close to the original solder points as possible. **Retain as much original wire as possible.**

Dismount all original components and mount new harness into pickguard.

Following the diagram, reattach pickups, ground wires and output jack.

Test for functionality and remount pickguard

**NEED HELP INSTALLING YOUR NEW GEAR?**

ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.

**855-655-9203**