


BRIDGE GROUND



T3W-TL-S0

COLOR CODE POSITIVE POESTIVE POINT NEGATIVE/GROUND NEW SOLDER POINT

INSTALLATION INSTRUCTIONS

Loosen pickguard from guitar and flip pickguard over.

Carefully cut original pickup & ground wires as close to the original solder points as possible. **Retain as much original wire as possible.**

Dismount all original components and mount new harness into pickguard.

Following the diagram, reattach pickups, ground wires and output jack.

Test for functionality and remount pickguard

NEED HELP INSTALLING YOUR NEW GEAR?
ONE OF OUR LOCAL INSTALL PARTNERS CAN HELP.
855-655-9203