

Fitting instructions for a DAVOSA rubber watchstrap

Fitting your DAVOSA rubber watchstrap is a simple six-step process.

You will need the following:



- Your DAVOSA watch
- DAVOSA rubber watchstrap with two suitable spring bars
- A suitable DAVOSA buckle with two suitable spring bars
- DAVOSA strap [changing tool](#)
- a measuring tape, use the one below
- Cutting tool
- *Optional:*
A pair of pliers or tweezers

We hope you enjoy your new DAVOSA rubber watchstrap.

Your DAVOSA team

1.

Release the spring bars

Press the spring bars together at the lug to release the strap from the case.

2.

Attach the watchstrap

Insert the spring bars into the openings provided on the lug end of each watch-strap section.



A. Push the strap with the spring bar into the opening on one side.



B. Push the spring in and slide the spring bar into the opening on the other side.

3.

Measure your wrist diameter

Use the DAVOSA size guide (below) for this purpose.

Please note:

DAVOSA is not responsible for incorrect printing or measuring. You will find the DAVOSA size guide [online](#).

4.

Determine length of watchstrap



Measure your watch with the watch-strap attached and add the length of the buckle.

5.

Shorten the watchstrap accordingly



Calculate the difference using your measurement from step 3. and shorten the strap equally on both sides. If you are uncertain, leave the strap a little longer at first, and shorten it further if needed.

6.

Attach the buckle to the watchstrap



Make sure that the logos on the buckle and the watch are correctly aligned. This will ensure that the buckle is fitted the right way round.

DAVOSA
SWISS

More information about our watches can be found at:

www.davosa.com

