

FLOOR LOOM LAMP HOLDER

ASSEMBLY INSTRUCTIONS

PARTS

- 1 – lamp holder
- 2 – 1-3/4" #8 trusshead screws

REQUIRED TOOLS

- Phillips screwdriver
- Drill and 1/8" drill bit

ASSEMBLY

1. Center the lamp holder on the castle side with the top of the lamp holder flush with the top of the castle side.
2. Insert the two screw provided into the holes in the lamp holder. With a hammer, gently tap the screws so that the points make an indentation on the castle side.
3. With a drill and 1/8" drill bit, drill holes approximately 1/2" deep where the screws indented the castle side.
4. Attach the lamp holder with the screws. Rub the screw threads with paste wax or bar soap to make them easier to turn.



lamp holder



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
p. 303.442.3212 f. 303.447.9273
© 2013 Schacht Spindle Company, Inc.

FLOOR LOOM LAMP HOLDER

ASSEMBLY INSTRUCTIONS

PARTS

- 1 – lamp holder
- 2 – 1-3/4" #8 trusshead screws

REQUIRED TOOLS

- Phillips screwdriver
- Drill and 1/8" drill bit

ASSEMBLY

1. Center the lamp holder on the castle side with the top of the lamp holder flush with the top of the castle side.
2. Insert the two screw provided into the holes in the lamp holder. With a hammer, gently tap the screws so that the points make an indentation on the castle side.
3. With a drill and 1/8" drill bit, drill holes approximately 1/2" deep where the screws indented the castle side.
4. Attach the lamp holder with the screws. Rub the screw threads with paste wax or bar soap to make them easier to turn.



lamp holder



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
p. 303.442.3212 f. 303.447.9273
© 2013 Schacht Spindle Company, Inc.