

CRANBROOK RADDLE

WW7211
WW7212
WW7213

FOR SCHACHT CRANBROOK LOOMS

PRE-ASSEMBLED RADDLE

- 2X 5/16" plastic spacer
- 2X 5/16-18 x 4" carriage bolt
- 2X 5/16-18 wing nut
- 2X 1/4" USS metal washer
- Extra pins

LOOM ATTACHMENT

- 2X 1-1/4" x 2" black knob
- 2X 1/4" plastic washer



ASSEMBLY

The holes for the pins have been pre-drilled at 1/2" intervals, and we have installed pins in half of the holes to make 1" intervals. Note that the center pin on the raddle has been painted black to mark the center of the raddle. If you prefer 1/2" intervals, fill the empty holes with the included extra pins. To install these pins, first loosen the wing nuts and remove the top of the raddle. Place the raddle on a sturdy surface such as the edge of a table directly above a table leg. Gently tap the pins into the holes with a hammer.

ATTACH THE RADDLE TO THE LOOM

On the loom, locate the holes with threaded inserts on the inside of each of the rear uprights of the loom, just above the steel back beam. Place a plastic washer on the screw end of a black knob and insert the knob through the hole on one end of the raddle. Repeat on the other end of the raddle. Place the raddle into position so that the knobs go into the threaded inserts on the loom. Tighten the raddle in place with the knobs.

NOTE: You will need a special attachment mount to install the Cranbrook Raddle on a Cranbrook Loom equipped with a double back beam; additional instructions will be included if necessary.



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
303.442.3212

© 2019 Schacht Spindle Company, Inc.

01.19