

SCHACHT TREADLE TRACKER

WT6521

SCHACHT TREADLE TRACKER

WT6521

SCHACHT TREADLE TRACKER

WT6521

No more taping a
draft to the front of
your loom!

The Treadle Tracker
places your pattern
in easy view.



No more taping a
draft to the front of
your loom!

The Treadle Tracker
places your pattern
in easy view.



No more taping a
draft to the front of
your loom!

The Treadle Tracker
places your pattern
in easy view.



PARTS

mounting bracket
clip stick
2X #8 Phillips screws

TOOLS REQUIRED

#2 Phillips screwdriver
drill and 1/8" drill bit

PARTS

mounting bracket
clip stick
2X #8 Phillips screws

TOOLS REQUIRED

#2 Phillips screwdriver
drill and 1/8" drill bit

PARTS

mounting bracket
clip stick
2X #8 Phillips screws

TOOLS REQUIRED

#2 Phillips screwdriver
drill and 1/8" drill bit

INSTALLATION

1. Determine the placement of your treadle tracker on the upper castle support of your loom. (On a low castle loom, this is the cross piece behind the shafts that connects the castle sides. On a high castle loom, this is the back side of the high castle tray.) You can center the mounting bracket on the loom or place it to one side.
2. Use the mounting bracket as a template to mark drill holes. With a 1/8" drill bit, drill two holes, 1/2" deep, in the upper castle support.
3. Set the bracket in position on the upper castle support with the lip of the mounting bracket toward the front of the loom. Use the screws to attach the bracket.
4. Place the clip stick in the bracket with the clip facing the front of the loom.

INSTALLATION

1. Determine the placement of your treadle tracker on the upper castle support of your loom. (On a low castle loom, this is the cross piece behind the shafts that connects the castle sides. On a high castle loom, this is the back side of the high castle tray.) You can center the mounting bracket on the loom or place it to one side.
2. Use the mounting bracket as a template to mark drill holes. With a 1/8" drill bit, drill two holes, 1/2" deep, in the upper castle support.
3. Set the bracket in position on the upper castle support with the lip of the mounting bracket toward the front of the loom. Use the screws to attach the bracket.
4. Place the clip stick in the bracket with the clip facing the front of the loom.

INSTALLATION

1. Determine the placement of your treadle tracker on the upper castle support of your loom. (On a low castle loom, this is the cross piece behind the shafts that connects the castle sides. On a high castle loom, this is the back side of the high castle tray.) You can center the mounting bracket on the loom or place it to one side.
2. Use the mounting bracket as a template to mark drill holes. With a 1/8" drill bit, drill two holes, 1/2" deep, in the upper castle support.
3. Set the bracket in position on the upper castle support with the lip of the mounting bracket toward the front of the loom. Use the screws to attach the bracket.
4. Place the clip stick in the bracket with the clip facing the front of the loom.



Find out more at schachtspindle.com
Schacht Spindle Company
6101 Ben Place Boulder, CO 80301
303.442.3212



Find out more at schachtspindle.com
Schacht Spindle Company
6101 Ben Place Boulder, CO 80301
303.442.3212



Find out more at schachtspindle.com
Schacht Spindle Company
6101 Ben Place Boulder, CO 80301
303.442.3212