WOLF TRAP

Assembly for

ALL WOLF LOOMS

FL3830 FL3831 FL3832

WOLF TRAP

FL3830 FL3831 FL3832

ASSEMBLY FOR ALL WOLF LOOMS



TOOLS REQUIRED

#2 Phillips screwdriver

PARTS

1X left side bracket 1X right side bracket

1X cloth sleeve

2X 1/2" diameter dowels

4X 6-18 x 1-1/4" Phillips flat head

sheet metal screws

ASSEMBLY

- 1. Slide the dowels into the casings on the long sides of the cloth sleeve.
- 2. Line up the side brackets with the large holes facing to the inside.
- 3. Fit the 1/2" diameter dowels into the holes in the side brackets. From the outside of the bracket, secure the dowels with 6-18 x 1-1/4" Phillips flat head sheet metal screws.
- 4. Place the assembled Wolf Trap onto the front beam of your loom.

1X 2X

1X

1X

PARTS

1X cloth sleeve 2X 1/2" diameter dowels

left side bracket.

right side bracket

4X 6-18 x 1-1/4" Phillips flat head

sheet metal screws

ASSEMBLY

- 1. Slide the dowels into the casings on the long sides of the cloth sleeve.
- 2. Line up the side brackets with the large holes facing to the inside.
- 3. Fit the 1/2" diameter dowels into the holes in the side brackets. From the outside of the bracket, secure the dowels with 6-18 x 1-1/4" Phillips flat head sheet metal screws.
- **4.** Place the assembled Wolf Trap onto the front beam of your loom.



Find out more at **schachtspindle.com** Schacht Spindle Company 6101 Ben Place Boulder, CO 80301 303.442.3212

© 2021 Schacht Spindle Company, Inc.



Find out more at **schachtspindle.com** Schacht Spindle Company 6101 Ben Place Boulder, CO 80301 303.442.3212

TOOLS REQUIRED

#2 Phillips screwdriver