# **1** Clean Air Kits

# **Exhalaron Filter Install**

**Unpack Filters** Remove the pair of HEPA filters from their box.

#### **Center Carefully**

Place filters between plates about 1/8" from plate edges. This should leave ~1/2" gap at center between them. The tips of the bungee slots should just meet the black filter gaskets. Attach the end bungees through slots in corners of bottom plates, forming a square loop at each end.

# Criss-Cross Central Bungees

Criss-cross central bungees on both sides into their bottom plate slots for slight tension. Examine the gasket seals between filters and plates. Turn filters or adjust bungees until no light gaps at cylinder ends.

Slip-On Shroud Slip on the filter shroud and align until filter grey mesh is no longer visible. The speaker-mesh shroud is machine washable.

## **Connect Power Bank**

If attaching a Power Bank, recross one of the side bungees over the top of the shroud, instead of behind so your Power Bank & its charge display will be visible. Connect the USBC PD to 12V Barrel Adapter cable to the DC Barrel socket and your Power Bank pigtail or other USBC cable.

Now tuck the cables behind the filter shroud, and slide Power Bank between the crossed bungees. Test Power Bank for substantial fan flow. Incompatible Power Banks may only output 5V which will leave fans very weak! Some Power Banks may have 20-30s delay before they ramp up to 12V mode, as indicated by a green symbol.

## Future Filter Changes

Just detach one end bungee at a time, slide filter out that end, replace with new filter, reattach end bungee loop, and repeat separately for the other end. Inspect seals then slip on washed filter shroud.

©2023 Rainbow Purifiers, LLC







