

# Travel Tin Candles Basic Instructions

## Materials and Equipment needed

Container / Votive wax

A double boiler for melting the wax or a metal container over a saucepan of hot water

Thermometer

Metal ladle

Old newspapers – to cover work area!

Apron is also a good idea!

Travel Tins

Suitable pre primed and stabbed Wick – this can vary according to the type of wax you use

Wick holder

Optional

- Wax Dye
- Wax Fragrance

## Instructions

1. ½ Fill bottom saucepan or base of double boiler with water - Start the water heating
2. Place wax in inner pot of double boiler
3. Tins should be warmed to approximately 40 °C and placed on protected work surface
4. Attach the wick with sustainer to the bottom middle on your Tin; our specially made glue dots are excellent for this. Check they're central & straight
5. Keep an eye on the wax temperature - Once the required pouring temperature is reached add the dye. Our dye is highly concentrated, add a little at a – note Colour will get lighter as the wax hardens
6. Add the fragrance oil (optional) and stir thoroughly
7. Pour wax into the tins and fill to about 1 cm from the top
8. Support your wick with a wick holder to keep it central
9. You may need to top up your candle slightly as it cools with more wax for a perfect finish
10. Allow to harden and cool completely
11. Trim wick to approx 5 mm
12. Allow the candle to rest for a minimum of 24 / 48 hours before burning

Now you have your very own Travel Tins!

**DO NOT pour wax down a drain – it will block it!**

**DO NOT pour water on the hot wax!**

Your candle making equipment can be cleaned by washing in hot soapy water.

Every care has been taken to compile this information accurately. In view of the fact that the application of this information is outside our control, we disclaim any liability incurred in connection with its application or use

FullMoons Cauldron™ PO Box 2173 Ascot SL5 0PQ Tel nr. 01344 627 945

[www.fullmoons-cauldron.co.uk](http://www.fullmoons-cauldron.co.uk)