

# ACRYLIC CLAWFOOT SLIPPER TUB

---



## INSTALLATION INSTRUCTIONS

### Tools Needed

Crescent Wrench

### Parts Provided

3 Bars: 1@17 inch bar 2@7 1/4 inch bars  
4 Bolts, 4 Washers, 4 Locking Washers  
4 Leveling Bolts

## Installation

1. Turn bathtub upside down.
  2. Remove nut from the bolts on the bottom of the tub.
  3. Affix 17 inch bar to bolts at the back of the tub, Affix the 2: 7 1/4 bars to the bolts at the front of the tub.
  4. Put Bolt, Washer, Locking Washer together, loosely tighten in hole.
  5. Place leg under the washer, tighten bolt (Repeat for other legs).
  6. Screw in the 4 leveling Bolts to the same level.
  7. Turn Bathtub rightside up, check level, affix plumbing.
-