

how to install part one – drilling the hole

- 1 Cut or drill an even, perpendicular hole in a marked location through the door using any of the following tools:



**DRIVER DRILL AND
HOLE SAW**



**ROTO-ZIP TYPE
ROUTER**



JIG SAW

NOTE: An 1/4" flange around the perimeter of the Doorlenz will cover any imperfections if the hole is slightly oversized or irregular in shape.

For more information on installation, view video at <http://www.youtube.com/watch?v=ScY7sWSQoDo>

WARNING: Wear protective glasses when using power tools.