



- 1) Lay down the back piece with the glue channels facing up and insert wood glue into the channels, insert the 2 uprights with tabs top and bottom in the outer channels.
- 2) Insert the middle two uprights in to one of the shelves, there is no need for glue here, then slide into relevant uprights already on the back piece. This will keep all the pieces aligned.
- 3) Add the rest of the shelves ensuring they slot in to the channels in the back piece.
- 4) Lay down the base and top with glue channels facing up, insert wood glue in to the channels.
- 5) Holding the shelves, uprights and back firmly together lift up and align the tabs of the uprights to the channels of the base piece, insert and press firmly together, repeat for the top piece.
- 6) Ensure all the pieces are firmly pressed together, plenty of glue has been used and all excess glue has been wiped off with a damp cloth.
- 7) Leave standing up for 24 hours to allow the glue to fully dry then your item will be ready to use. Clamps can be used if available, if not a heavy book/object on top will suffice.

Fully assemble BEFORE painting!

PLEASE NOTE: Only use a good quality wood glue Hot glue, superglue etc will not work!

Always dry fit first (assemble without glue) to ensure you know how it fits together

Any queries please call 02891 246356 where someone will be able to assist you.