

Assembly Diagram: 798 - Bobbin Holder

Always dry fit first then use a suitable wood adhesive

Fully assemble BEFORE painting!

