

Assembly Diagram: 805 - Kallax Drawer Unit (ABB)

Always dry fit first then use a suitable wood adhesive

Fully assemble BEFORE painting! Top

