

Assembly Diagram: 877 - Aerosol Stand

Always dry fit first then use a suitable wood adhesive
Fully assemble BEFORE painting!

