

Assembly Diagram: 887 - 3 section A4 storage

Always dry fit first then use a suitable wood adhesive

Fully assemble BEFORE painting!

