

Assembly Diagram: 888 - 3 section A4 storage with drawer

Always dry fit first then use a suitable wood adhesive
Fully assemble BEFORE painting!

