

## Assembly Diagram: 890 - 12x12 & A4 storage

Always dry fit first then use a suitable wood adhesive  
**Fully assemble BEFORE painting!**

