

Assembly Diagram: 932/911 - Santa Sleigh Freestanding

Always dry fit first then use a suitable wood adhesive before painting the sleigh

Step 1 - Lay out pieces as shown for dry fitting



Step 2 - Once you are happy with the layout take the centre pieces and place them into the side panel. Gluing them into place one at a time



Step 3 - Glue on the second side panel

