

# Assembly Diagram: 954 - Large 3 tier display unit

Always dry fit first then use a suitable wood adhesive

