

Assembly Diagram: J016 - A4 Paper Storage

Always dry fit first then use a suitable wood adhesive

