



OG Exhaust - READ BEFORE INSTALL!

1. THRASHIN recommends to put new tapered style exhaust port gaskets, as well as retaining rings.
2. Mount bracket to transmission finger tight with medium thread lock.
3. Install pipe to cylinder heads.
4. Put clamp on muffler. Now slide the muffler onto the head pipe using anti seize at the slip fitting.
5. Mount the muffler to the transmission bracket, use medium thread lock.
6. Tighten the entire exhaust evenly so the exhaust seats itself without any mounting point being pulled.
7. Check all hardware torque after first hear cycle and frequently. These are Harleys and they VIBRATE!
8. THRASHIN recommends to get the bike properly tuned. Running this pipe untuned can cause excessive heat and weaken material.