

BLK BOX LANDMINE ASSEMBLY

1

BOLT LANDMINE ATTACHMENT TO OUTSIDE OF UPRIGHT. ENSURE THAT THE PLASTIC WASHERS (BLACK) ARE PLACED EITHER SIDE OF THE UPRIGHT. DO NOT OVER TIGHTEN TO ALLOW FOR SMOOTH ROTATION.

