

# Installation Instructions for:

## 2262 – Lever Arm Bracket Kit

## 2270 – Lever Arm and Bracket Assembly

### Parts List for 2262 & 2270:

- Lever Arm Bracket
- 2 screws size 10-32 x 1.125"
- 3 Screws size 10-32 x 0.75"
- 5 lock nuts size 10-32
- **2270** also has the Lever Arm (Individually sold as **2260**) in the addition to the above

### Converting from the Mounting Block to the Bracket System

- First, you must remove the five existing screws. These screws will be replaced the screws in the kit. Find the "Hydrobikes" logo located on the top half of the drive, opposite side of the propeller.
- Starting just below the logo take out the first 3 screws along the right side (shorter ones) and the 1<sup>st</sup> and 3<sup>rd</sup> screw along the left (the longer ones).
- Hold the bracket up and place the screws in the correct holes (3 short on the right and 2 long on the left).
- **\*Do not put the nuts on until all screws are in first.**
- Once all 5 screws are in, start putting on the nuts, keeping them all loose.
- After they have all been started you can go ahead and tighten them.



### Installing the Lever Arm into the Bracket (if applicable)

- Press in the two silver push buttons on the lever arm
- Slide it into the side of the bracket by the logo
- Guiding it until the push buttons rest in the 2 holes on the bracket.