

Condo Guard Installation



Our newly redesigned condo guards help keep hay, small stows and STUFF inside the condo! Installation is a snap. This new design is not compatible with the older style that hung on the outside of the condo using metal holding clips.

The condo guards are easily installed with the condo top off, however it is not necessary. You can install our condo guards onto an already constructed condo. We used a condo without the top on for easy photo purposes.

1. You'll begin with three strips of plexiglass and ten plastic clips. And, of course, a Bunny Abode Condo! As plexiglass is clear, we've left the protective coating paper and label on one of the pieces in our instructional pictures so you can see it clearly. If your plexiglass comes with a film on it, remove the film before installing the condo guards.
2. Start with the backside of the condo. The clear plexiglass guards fit into the groove on the outside of the wire. Push the wire forward to make room. Just place your thumb against the bottom wire and firmly push forward.
3. Insert the longest strip of plexi into the groove. Start with one end, angled down sharply as shown. Once it's seated, just push the rest of the length down into the groove until you've reached the other end.
4. Repeat with the two sides. First, push the wire in the opposite direction, then insert the shorter piece of plexi into the groove.
5. Repeat with the other side. The last side may be a tight fit. (No picture for this one!)
6. Next, install the plastic clips on all three sides. You'll use three clips on each short side, and four on the back side. Space them equally. It's easiest if you hook the clip from the inside, first over the wire, then over the plexiglass. They clip on firmly, to hold everything in place.
7. Tada! Your new condo guards are installed! Repeat steps 1-6 for each level of your condo.

