

IMPORTANT  
FERMENTERS AND BRITE TANKS  
WITH GLYCOL JACKETS

Please note that your jacket pressure rating is 15PSI. Relief valves should be installed in your glycol line to activate and re-route the flow of glycol to the return loop in the event of overpressure.

Solenoid valves should be installed on the inlet side of your tank (the  $\frac{3}{4}$ " pipe with the 90 degree bend) (glycol loop > manual shutoff valve > solenoid > Tank inlet). Observe solenoid flow direction.

If you have questions about the connection of tanks, email [cobrewingsystems@gmail.com](mailto:cobrewingsystems@gmail.com) for support. Failure to follow these instructions can result in damage to the cooling jacket and tank.