Installation Instructions

····· for reusable decals ···

Important! Please install 1 decal as a test before installing the full set. We recommend waiting 1-2 days before installing the rest of the decals, as most adhesion issues usually occur within the first 48 hours. :)

1

Clean and thoroughly dry your wall before installation. Use a damp wash-cloth to wipe down your wall and allow it to completely dry before applying the decals. Do not use cleaners that leave behind any residue. If decal sheets are curling, you can lay them flat and weigh down the edges for a few hours. If you are applying your decals to newly painted walls, we recommend waiting 3 weeks for the paint to fully cure before installing the decals.

2

To remove the decals from the backing paper, **gently bend the backing paper along the edge of the decal**, allowing you to lift up the edge of the decal with your fingertips. Gently and slowly peel off the decal from the backing paper. Avoid getting any liquids or oils from your hands on the sticky side of the decals.

3

Place the sticky side of the decal on your wall, and gently smooth over the top of the decal with your hand. These decals can be removed and reapplied, so if you are unhappy with the initial arrangement of the decals on your wall, you can rearrange them by gently peeling the decals off your wall and reapplying them. **Avoid getting dust/debris on the sticky side of the decal**, as this can affect the decal's ability to fully adhere to your wall.

Removal & Storage

Gently peel decals off your wall and place back onto the original backing paper. Store at room temperature with 50% or less humidity. To avoid creasing, do not fold or bend the decal sheet.

Safety Info

All decor with small and/or removable parts should be kept out of reach of children as it may present a choking hazard if swallowed. We recommend keeping this in mind when you are placing these decals!:)

Please note: These decals (and all self-adhesive decals) may have trouble adhering to heavily and/or tightly textured walls and walls with eco-friendly or low VOC paint. Please install 1 decal as a test and wait 48 hours before applying the rest of the decals to ensure your decals won't have problems adhering.