



# Yamaha G29 Seat Set Installation Guide

## Tools Needed

- Clean Workspace
- Socket Wrench
- Safety Glasses
- Allen Wrench

## Hardware Contents

- (4) 11/16" Spacers
- (4) Back Rest Washers
- (4) 2.5" Back Rest Bolts
- (8) Seat Hinge Washers

Missing hardware? Call 855-732-8669 - we'll send right away at no cost to you



## Old Seat Removal

- Detach the back rest from the cart frame by removing the 4 bolts. These bolts can be discarded as they will be replaced with the provided screws from the hardware pack.
- Pull your seat cushion forward and lift away from the hinge receivers on the cart. Detach each hip restraint and seat hinge from the seat by removing each bolt. Set all components (bolts included) aside for installation with the new cushion.

**NOTE:** To ensure a clean seat installation, use soap and warm water to remove any dirt build up from your hip restraints before mounting to your new seat cushion

## Seat Hinges

**NOTE:** The washers are used to stage each seat hinge so that the seat cushion folds down properly with a flush fit.

Center (2) washers above each bolt hole on left side for hinge installation. Place seat hinge on top of stacked washers and hand tighten with original hinge bolts. Ensure a parallel alignment with the seat board and complete mounting process using allen wrench. Repeat on right side.

## Hip Restraints

Line up the short restraint (driver's side) with the hole pattern on the new seat board. Using original restraint bolts, hand tighten each bolt to ensure a proper alignment. Once all 4 bolts are in place, complete mounting process using socket wrench. Repeat step for long restraint (passenger's side).

## Seat Cushion

After hinges and restraints are mounting to your seat cushion, you're ready to place on your golf cart. Line each hinge up with the receiver brackets on the cart and place into the slots. Gently lower the cushion so that the seat folds down.

## Back Rest

Place washer on each back rest bolt prior to inserting into cart frame. Start with top left bolt hole, and place bolt into frame. Place spacer onto bolt before inserting into new back rest. Hand tighten. Repeat for bottom right bolt hole and again for top right and bottom left. Once all 4 bolts have been set, complete mounting process with socket wrench.