

AFTERMKT ARMOR



2A Bedliner (Black)

90-0214-KIT

2A Bedliner is a two component, UV resistant, textured bedliner. It is intended for cosmetic improvements to old trucks with deteriorated, scratched or scuffed up beds and to protect new truck beds from damage. When cured it provides a tough, flexible, mar resistant, water proof and solvent resistant coating. Contents of box should cover a 5.5' short bed and additional quarts can be purchased separately to finish a larger job.

Substrates for Acceptable Application

- Painted or primed steel
- Galvanized steel
- Aluminum
- Epoxy or self etched primed substrate

Surface Preparation

Wash surface with soap and water. Rinse well and wipe dry with a clean cloth. Solvent clean surface and wipe completely dry. Sand bare metal with 80-150 grit. Sand existing finishes with 220 grit. For improved durability user may want to use Acrylic Urethane Primer or Epoxy Primer. *Note: For solvent needs and other automotive paint products contact your local automotive store for suggested options.*

Mixing & Application

Mix: Using the enclosed mixing cup, add 8 oz of activator (90-0204) to the bedliner (90-0214). Close top and shake well to activate product. Once mixed, attached enclosed Schutz gun to the Bedliner Part A can and product is ready for application. Pot life of activated product is 4 hours (@70°F (21°C) and 50% R.H.)

Application

Spraying: Apply 2 coats using air pressure of 40 - 60 psi on the Schutz gun. First coat should be applied in a heavy wet pattern, second coat in a medium pattern and the third coat, if required, is sprayed away from the panel using a mist technique. Flash for 20-40 minutes between coats. Can be force dried for 40 minutes @ 140°F (60°C) after a 30 minute flash time. Clean Schutz gun immediately after product application using gun cleaner or solvent wash.

Rolling: Bedliner can be applied as a roll on bedliner. Mix same as above and pour into disposable paint tray. Start by cutting in all the corners and hard to reach areas with a brush. Using a 4" foam textured bedliner roller, apply slowly to the main areas using a medium to light pressure. Allow up to 40 minutes to flash between coats.

Note: Rolling may result in lower film builds and require additional coats.

Dry Time

Truck bed will be firm to touch between 8 - 16 hours.

Use recommendation: 2 - 3 days for light duty and 5 - 7 days for regular duty.

Rev 07/23