

868

Additional Instructions

Assembling the tape guide

IMPORTANT READ CAREFULLY BEFORE USE KEEP FOR FUTURE REFERENCE

All rights reserved.

Property of Dürkopp Adler GmbH and protected by copyright. Any reuse of these contents, including extracts, is prohibited without the prior written approval of Dürkopp Adler GmbH.

Copyright © Dürkopp Adler GmbH 2020



1	Components of the kit	3
2	Assembling the kit	4





1 Components of the kit

Check whether the scope of delivery for the kit is correct prior to assembling the tape guide. Different kits are available that vary with the width of the tape. The installation procedure is the same for all kits.

Kit	Tape width
N522 025021	14 mm
N522 025031	16 mm
N522 025041	18 mm
N522 025051	20 mm

Components of the kit

Part no.	Number	Description		
N522 005009	1	Guide		
N522 005024/ N522 005034/ N522 005044/ N522 005054	1	Tape guide 14 mm 16 mm 18 mm 20 mm		
N522 005025/ N522 005035/ N522 005045/ N522 005055	1	Tape insert 14 mm 16 mm 18 mm 20 mm		
N522 005026/	1	Regulating washer		
0992 023980	1	Screw M3x2.8		
0992 009580	1	Screw no. 89x4		
0992 023677	1	Screw M4x4,3		
N522 005007	1	Flap		
N522 005006	1	Guide		
9203 003667	2	Screw M4x10		
9203 003657	1	Screw M4x8		
9330 000087	2	Washer A4.3		
9330 200097	2	Washer A4.3		
N522 005008	1	Plate		
9207 150147 2		Screw 3.0x16		
9207 160347 2		Screw 3.0x16		
N900 001527	1	Tape roll holder		
N900 001601	1	Tape roll holder		



2 Assembling the kit

WARNING



Risk of injury from moving, sharp parts!

Puncture and crushing possible.

Switch off the machine before assembling the kit.

WARNING




Risk of injury from heavy parts!

Crushing possible.

Make sure that your hands do not reach under the machine.

Fig. 1: Removing the slot



(1) - Piece of plastic

(2) - Oil pan



1. Before installing the oil pan (2), remove the piece of plastic (1) so as to create a slot.




(3) - Slot (4) - Guide (2) - Oil pan (5) - Tabletop

Fig. 2: Fixing the guide in place at the tabletop



2. Fix the guide (4) in place at the tabletop (5) in such a way that it is seated in the slot (3) of the oil pan (2); if necessary, pre-drill 2 mm into the tabletop to prepare the holes.







3. Pre-assemble the tape guide as shown above.






Fig. 4: Assembling the tape guide at the tabletop

- (5) Tabletop
- (6) Tape

4. Use screws (8) to fix the tape guide (7) in place at the tabletop (5) in such a way that the tape (6) is positioned at the center of the needle.

Fig. 5: Assembling guides



(9) - Guide


(10) - Guide



- Fix the guide (9) in place using washers and screws.
- 6. Fix the guide (10) in place using the screw.




Fig. 6: Pre-assembling the guide






- 7. Assemble the spacer piece (11) with the screw (12) on the guide (13).
- 8. Clamp the tape insert (14) into the guide (13).

Fig. 7: Assembling the guide



(13) - Guide

(15) - Plate





9. Fix the guide (13) in place using the screw (16). If screw (16) and hole do not line up on top of each other, loosen the entire plate (15) again and align it properly.



Fig. 8: Threading the tape





10. Thread the tape as shown in the figure. The tape must be guided to the needle without twisting.



Information

If the tape does not pass without resistance between base plate and tabletop, CAREFULLY file off a small portion of the tabletop.



DÜRKOPP ADLER GmbH Potsdamer Str. 190 33719 Bielefeld Germany

Phone: +49 (0) 521 925 00

Email: service@duerkopp-adler.com

www.duerkopp-adler.com