

# Lights of Modern

PD1043-8BL

## ⚠ WARNINGS AND CAUTIONS

- Make sure POWER is COMPLETELY OFF at the fuse box
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area
- Wear gloves at all times during this installation
- Read instructions carefully before you start assembly
- Keep this installation sheet for future reference

### Please Note:

In regular circumstances the BLACK wire will be “L/live”, WHITE will be “N/neutral” and GREEN or BARECOPPER will be “GND/ground”. In older buildings it is always good practice to reconfirm the polarity of the wiring.

## NOTICE

- The important safeguards and instructions outlined in this sheet can not cover all possible conditions and situations that may occur. It must be understood that caution and certain care factors must be followed. These instructions are provided for your safety and we highly recommend that a licensed, trained electrician install this unit.
- This fixture is designed to be mounted on a correctly installed standard round or octagon box OR through a wiring box with a plaster frame. The box must be securely mounted to the structure of the building. The cross bar and hardware supplied should be used, directly mounting the fixture to the outlet box may make it impossible to correctly align the fixture.

## ASSEMBLY INSTRUCTIONS

### Step 1

Separate mounting plate (A) from canopy (B) by removing canopy screws (C). Do not discard the canopy screws (C) as these will be used later.

### Step 2

Attach mounting plate (A) to electrical junction box using junction box screws (Dx4) provided in hardware package.

### Step 3

Gently pull the existing wire down from the ceiling junction box and allow wires to hang through the center opening of mounting plate.

### Step 4

To change fixture height, loosen the Set Screws (F) from the Collars (E) under the Canopy (B), adjust the wire to desired length and then secure the wire by tightening the set screws on to the Collars.

### Step 5

Make proper electrical connections (black to hot “L”, white to neutral “N”, ground to “GND”) with wire nuts (Gx2) provided in hardware package.

### Step 6

Attach canopy (B) to mounting plate (A) with canopy screws (C).

### Step 7

Unscrew the socket rings (Q) from the sockets (N). Put the glass shades (O) (packed separated) onto the sockets (N), secure glass shades by rotating the socket rings (Q) in a clockwise direction until tight.

### Step 8

Insert light bulbs (not included) into the sockets (N).

