

# Air Dam (Part No. MM024 / MM024A)

This item requires careful fitting. Offer up the air dam to your visor and mark the three holes for fixing the air dam to the visor. Drill the three holes with a 3.2 mm [1/8"] drill. The drill **MUST** be sharp and the drilling speed low. Fasten the air dam to the visor using the three nylon screws provided; **DO NOT** over-tighten the screws. Cut off the excess screw and lock the screw with a little locking compound. Do not get any locking compound on the visor.

MicroAvionics, England  
[www.microavionics.com](http://www.microavionics.com)