

Step 5: Screw in screws leaving approximately 1cm exposed.

Step 6: Slip the slotted holes in the back of the clock down and onto the screw head. Keeping the clock against the wall, you can try and move the clock side to side or up and down to confirm a good grip.