



**BRAMWELL
BROWN**

Clock Hanging Template

N.B. Further instructions can be found in your instruction manual, however, please note that your clock should not be hung closer than 50cm to a hot radiator or in a location where it will be exposed to high temperatures.

Step 1: Relax, you've got this. Hanging your clock shouldn't be stressful and with just the same care of hanging a framed picture, your clock will be firmly anchored on the wall!

Step 2: Position template on wall in desired location, ensuring horizontal line is level.

Step 3: Drill in the location marked in red.

Step 4: Insert wall plugs appropriate to the type of wall you are mounting on.

Step 5: Screw in screw leaving approximately 1cm exposed.

Step 6: Slip the slotted holes in the back of the clock down and onto the screw head. Keeping the clock against the wall, you can try and move the clock side to side or up and down to confirm a good grip.