

OUTRIDE
THE
ORDINARY

INSTALLATION GUIDE	
PART KIDS FOOT REST	SKU S0755
COLOUR BLACK	WEIGHT 0.253 KG

@coastcycles
<http://coastcycles.com>

CONTENT PAGE

REQUIRED TOOLS	2
BOX CONTENTS	3
INSTALLATION PROCEDURE	4

COMPATIBILITY

BUZZRAW CLASSIC



BUZZRAW PRO



BUZZRAW SL



REQUIRED TOOLS

TOOLS

5mm Hex Wrench
10mm Socket Wrench or Spanner
Torque Wrench

BOX CONTENTS

Kids Foot Rest	- 1 pc
M6 x 60mm Allen Head Bolt	- 1 pc
M6 Saddle Washer	- 1 pc
M6 Nylon-insert Lock Nut	- 1 pc



(Fig. 1) Kids Foot Rest and the appropriate hardware.

INSTALLATION PROCEDURE

Insert the M6 x 60mm bolt through the foot rest. The head of the bolt will rest on the flat surface of the foot rest as shown. (Fig. 2 & 3)



(Fig.2) Orientation of the bolt through the foot rest.



(Fig. 3) Orientation of the bolt through the foot rest.

The appropriate mounting point for the foot rest will be the down-tube crossbar that is located closest to the frame bumpers. (Fig. 4 & 5)

Insert the bolt through the mounting hole in the tube. (Fig. 5)



(Fig. 4) The mounting point will be the topmost bar on the down tube.



(Fig. 5) Insert the foot rest and bolt as shown.

Note the curve on the saddle washer. The curved part of the washer will face the frame. (Fig. 6)



(Fig. 6) Note the orientation of the saddle washer.

Place the washer over the bolt and thread the M6 nut onto the bolt. (Fig. 7)

Use a 5mm Hex wrench to prevent the bolt from turning. Tighten the M6 nut to **6 Nm**. (Fig. 8)



(Fig.7) Washer and M6 Nut.



(Fig. 8) Tighten the M6 Nut to **6 Nm**.

Installation is complete. (Fig. 9)



(Fig. 9) Completed Installation.

For further enquires, please contact us at

enquires@coastcycles.com

Design Office

54 Siglap Drive.
Singapore 456176
(65) 6681 6681

Head Office

Vijzelgracht 7, 1017 HM
Amsterdam, Netherlands

(31) 20 716 3925

COASTCYCLES