

Assembly Instructions For **23-GLS** Glass Door Kit for 2-pc. Rail & Stile Router Bits (91-501 through 91-506)



Kit Contents:

(1 ea.) ½" Slot Cutter (1 ea.) %" O.D. Bearing (5 ea.) 0.004" Shims (1 ea.) 0.015" Shim

Stile Cutter Assembly:

- 1. Remove the top nut, washers, bearing, and slot cutter from the stile cutter router bit.
- 2. Do not remove the original three shims.
- 3. Install all of the shims included in the 23-GLS kit onto the bit.
- 4. Install the $\frac{1}{2}$ " slot cutter onto the bit with the Infinity logo face-up and visible.
- 5. Reinstall the washer and nut onto top of bit and torque to specifications (8-11 ft. lbs.).
- 6. Store the original bearing, ¼" slot cutter, and additional washer in a safe location.

Rail Cutter Assembly:

- 1. Remove the top nut, washers, and slot cutter from the rail cutter router bit.
- 2. Do not remove the original three shims.
- 3. Install the %" O.D. bearing included in the 23-GLS kit.
- 4. Reinstall the washer and nut onto top of bit and torque to specifications (8-11 ft. lbs.).
- 5. Store the original slot cutter in a safe location.