



Tailpiece Ground:

There is a loose black wire in the bag of parts. One end should be soldered to the board where indicated. The other needs to make contact with the metal pieces of the tailpiece. On the bottom of the body are three holes drilled for the tailpiece, in a triangle shape.

Drill a 4th hole in the center. Strip back a small section of the wire and run the bare portion out that 4th hole. As the tailpiece is secured, it will make contact with the bare wire and complete the ground circuit.