



# 7 Rules To Strip By

## 1/ LESS IS MORE

It is easier to do more passes removing the paint slowly than trying to sand out wood that has been damaged by going to deep to quick.

## 2/ SMALL TURNS

Using the 'T' allen key you can adjust to take off more or less paint, a 1/12th turn is approx a layer of paint.

## 3/ START AT THE BOTTOM

If the board has cupping you will be able to remove this if you work up the face of the weatherboard.

## 4/ FROM RIGHT TO LEFT

It only works one way, start on your right and work left.

## 5/ LET THE TOOL DO THE WORK

You should not need to press really hard, apply just enough pressure to keep the tool flat against the weatherboard.

## 6/ DOING THE BOTTOM LIP

Do this separately after finishing the face as it is considerably easier than trying to do both at the same time

## 7/ ROTATING THE BLADES

Rotate all 3 blades at the same time in the same direction

Lastly Practice up high around the back until you get the hang of it