



Strut Clamp Mount Instructions

www.Nflightcam.com



ITEMS NEEDED

1. Strut Clamp
2. Exterior Ball-Head Mount
3. Rubber Strap
4. 5/32" Hex Key (included, but not shown)



STEP 1

Place rubber strap through top slot on strut clamp. Ensure that the tongue of the metal clasp on the rubber strap faces away from the strut.



STEP 2

Loosely wrap the rubber strap around the strut.



STEP 3

Thread the rubber strap through the bottom slot of the strut clamp.





Strut Clamp Mount Instructions

www.Nflightcam.com



STEP 4

Thread the rubber strap through the metal clasp.



STEP 5

Pull the rubber strap tight.



STEP 6

Ensure the tongue of the metal clasp is secured into one of the holes in the rubber strap.



STEP 7

Secure the excess portion of the rubber strap. The strap may be cut to length or folded and secured with a zip tie. If you decide to cut the strap to fit, make sure to leave at least 6 inches or 10cm of material.

